


Rig Control & CW/PTT
From PC USB Port
4-DTR CW 7-RTS PTT

From KPA500
"XCVR" conn.

KPA500: 5 GND, 10 KEY-IN



To Radio RS-232 or P3 "PC" Conn.
KXSER cable
to KX2
(optional)

To ACOM Only (from ICOM)

TXD (tip) **RXD** (ring1) **CW** (ring2)
 Dual RCA Jack Dual RCA Jack OUT (ring2)

N6TV		
1x3 DE-9 Splitter with DE-15		
R. A. Wilson	Ver 1.2	Page 1 of 1
	03/05/2018	